

# HOOD




















## USER INSTRUCTIONS

FOR LITE, STURDY,  
PUSH AND MINI



# WARNINGS

## PLEASE READ BEFORE USING THE PRODUCT

-  **WARNING!** A child's safety is your responsibility.
-  **WARNING!** Read the instructions BEFORE use.  
Keep these instructions for future reference.
-  **WARNING!** Never leave a child unattended.  
It may be dangerous to leave your child unattended.
-  **WARNING!** This wagon is not intended for children under 3 years.
-  **WARNING!** Maximum load of the BEACHWAGON LITE is 80 KG.  
Never overload.
-  **WARNING!** Never let a person stand in the wagon.
-  **WARNING!** This wagon is not suitable for running or skating.
-  **WARNING!** Assembly of the BEACHWAGON LITE by adults only!
-  **WARNING!** This wagon should be used with caution, since skill is required  
to avoid falls or collisions causing injury to the user or third parties!
-  **WARNING!** Do not attach the wagon to any other vehicle, car, bicycle, motor or animal.  
Do not use on highway. Only use for walking. Maximum speed 10 KM per hour.
-  **WARNING!** Always use this wagon with care to avoid injury, falling and collision.
-  **WARNING!** Always divide the load evenly over the wagon.  
Overloading on one side might cause tilting of the wagon.
-  **WARNING!** When the wagon is used in the sun, there is a hazard of sun burn.  
Use sun protection for children.
-  **WARNING!** Keep flames and heat away from the wagon.
-  **WARNING!** This wagon requires regular maintenance by the user.  
See the maintenance instruction in this manual.
-  **WARNING!** Ensure that all accessories are engaged/constructed according  
the advised instructions in the manual of these accessories before use.
-  **WARNING!** To avoid injury ensure that your child is kept away from the wagon  
when unfolding and folding this wagon.
-  **WARNING!** Keep plastic covers and bags away from children to avoid suffocation  
and hazard.
-  **WARNING!** Children should be kept on a distance of moving parts while  
making adjustments.



# INSTALLATION

Top unfolded



Available for Lite, Sturdy, Mini and Push

Lock in place by clamping to the sides of the wagon

Fold top over the edges of the wagon for a snug fit

**BE SURE TO CHECK OUT OUR WIDE  
RANGE OF ACCESSOIRES!**



**AND MUCH MORE AT  
[WWW.BEACHWAGONSTROLLERS.COM](http://WWW.BEACHWAGONSTROLLERS.COM)**